

Operating Manual

for

novopress

HSBL2 Hole punch 160 Digital



Contents

Page

- CE Conformity declaration
- Safety regulations
- HSBL2 Hole punch 160 Digital, Order no.: 40280 and HSBL Hydraulic cylinder, Order no.: 2420 1
 - Range of application 1
 - Technical data:..... 1
 - Commissioning 2
 - Tool installation 4
 - Punching 5
 - Tool assembly..... 6
 - Upper tool section 6
 - Lower tool section 6
 - Instructions for using the tools 7
 - Maintenance 8
- Guide system with roller conveyor and table..... 9
 - Range of application 9
 - Technical data..... 9
 - Commissioning/Punching 10
- Operating the digital display of the measuring system..... 11
 - Battery charge level 11
 - Setting the x-axis to zero 11
 - Setting the y-axis to zero 12
 - Resetting the digital display 12
 - Setting the incremental dimension..... 13
 - Conversion of mm into inches and vice-versa 13
 - Setting of parameters..... 14
 - Exiting the parameter menu 14
 - Inputting a parameter:..... 14
 - Adjusting the x-axis zero setting 16
 - Adjusting the y-axis zero setting 17
- Assembly 18

CE - KONFORMITÄTSERKLÄRUNG

entsprechend EG-Maschinenrichtlinie 98/37/EG, Anhang II A

Novopress GmbH & Co KG
Scharnhorststr. 1
D-41460 Neuss

HSBL2 Lochstanze 160 Digital

Ser-nr:

1. EN 294, EN 349, EN ISO 9001

Hiermit erklären wir, daß die nachfolgend bezeichnete Maschine aufgrund Ihrer Konzipierung und Bauart sowie der von uns in Verkehr gebrachten Ausführung den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen entspricht.
Bei einer nicht bestimmungsgemäßen Anwendung der Maschine oder bei einer nicht mit uns abgestimmten Änderung der Maschine verliert diese Erklärung ihre Gültigkeit.
Die Konformitätserklärung ist nur gültig, wenn die Maschine mit dem Hydraulikaggregat HA1ES oder HA3 betrieben wird.

Angewandte harmonisierte Normen, insbesondere:
siehe Punkt 1

Angewandte nationale Normen, insbesondere:
siehe Punkt 2

We hereby declare that with respect to its design and construction the machine stated below and the model thereof which we have brought into circulation conform with the applicable basic requirements on health and safety.
Any use of the machine other than that for which it is intended and any modification made thereto without our consent shall render this declaration null and void.
This declaration of conformity shall only be valid if the machine is operated with hydraulic unit HA1ES or HA3.

Applied harmonized standards, in particular:
see Item 1 above

Applied national standards, in particular:
see Item 2 above

Nous déclarons par la présente que par sa conception et son type ainsi que par l'exécution que nous avons mise sur le marché, la machine désignée ci-après répond aux exigences de sécurité et de prévention de la santé applicables.
La présente déclaration perd sa validité si la machine n'est pas utilisée conformément aux instructions ou dans le cas d'une modification de la machine à laquelle nous n'avons pas donné notre accord.
La déclaration de conformité n'est valable que si la machine est utilisée avec le groupe hydraulique HA1ES ou HA3.

Normes harmonisées utilisées, en particulier :
voir point 1

Normes nationales utilisées, en particulier :
voir point 2

Hiermede verklaren wij, dat de hierna genoemde machine op grond van haar constructie en type alsmede de door ons in de handel gebrachte uitvoering aan de desbetreffende fundamentele eisen ten aanzien van de veiligheid en de gezondheid voldoet.
Wordt de machine niet overeenkomstig haar bestemming gebruikt of worden hieraan niet met ons overeengekomen wijzigingen aangebracht, dan verliest deze verklaring haar geldigheid.
De conformiteitsverklaring is slechts geldig, indien de machine met het hydraulische aggregaat HA1ES of HA3 wordt aangedreven.

Toegepaste geharmoniseerde normen, in het bijzonder:
zie punt 1

Toegepaste nationale normen, in het bijzonder:
zie punt 2

Datum / Herstellerunterschrift: 01.08.05
Angaben zum Unterzeichner:



Geschäftsführer

Con la presente declaramos que la máquina denominada a continuación, por su concepto y por su construcción, cumple con los requisitos fundamentales de seguridad y sanidad en vigor. Lo dicho aplica exclusivamente a la máquina en su versión original, tal y cual ha sido fabricada por nosotros.

El empleo inapropiado de la misma, así como cualquier modificación ejecutada sin nuestra intervención hace que esta declaración pierda su validez.

Para que esta declaración de conformidad tenga validez, la máquina se habrá de operar categóricamente con un grupo hidráulico tipo HA1ES o tipo HA3.

Normas armonizadas aplicadas, en particular:

véase bajo el punto 1

Normas nacionales aplicadas, en particular:

véase bajo el punto 2.

Si dichiara che la macchina appresso descritta soddisfa, per concetto, tipo e modello messo in commercio, le esigenze di base di sicurezza e sanità relative a tali apparecchiature.

In caso di uso non appropriato della macchina o in caso di una sua modifica eseguita senza il nostro accordo, questa dichiarazione non ha più effetto.

La dichiarazione di conformità è valida solo se la macchina è messa in funzione con il gruppo idraulico HA1ES o HA3.

Norme armonizzate applicate, in particolare

vedi punto 1

Norme nazionali applicate, in particolare

vedi punto 2

Härmed försäkrar vi att nedan nämnd maskin motsvarar de tillämpliga och principiella säkerhets- och hälsoföreskrifterna både gällande koncipieringen och konstruktionen samt gällande den av oss sålda modellen.

Används denna maskin inte enligt anvisningarna eller förändras maskinen på ett sätt som vi inte har godkänt, gäller denna försäkran ej.

Konformitetsförsäkran gäller endast om maskinen drivs med hydraulikaggregat HA1ES eller HA3.

Tillämpade harmoniserade normer, i synnerhet:

se punkt 1

Tillämpade nationella normer, i synnerhet:

se punkt 2

Täten vakuutamme, että seuraavassa nimetty kone vastaa suunnittelunsa, rakenteensa sekä meidän taholtamme liikenteeseen päästetyn mallinsa puolesta asiaankuuluvia perustavaa laatua olevia turvallisuus- ja terveystämääräyksiä.

Jos konetta ei käytetä määräysten mukaisesti tai jos koneeseen tehdään muutos ilman meidän suostumustamme ei tämä selvitys enää päde.

Standardinmukaisuusselvitys on vain silloin voimassa, kun konetta käytetään hydraulisen yksikön HA1ES tai HA3 kanssa.

Käytetyt harmonisoidut standardit, varsinkin:

katso Kohta 1

Käytetyt kansalliset standardit, varsinkin:

katso Kohta 2

Herved erklærer vi at den i det følgende betegnede maskinen på grunn av dens konsipering og konstruksjon samt utførelsen som vi har brakt på markedet tilsvarende de respektive grunnleggende krav til sikkerhet og helse.

Ved en bruk av maskinen som ikke er formålstjenlig eller ved en endring av maskinen som ikke er avstemt med oss mister denne erklæringen sin gyldighet.

Konformitetserklæringen er bare gyldig hvis maskinen drives med hydraulikkaggregatet HA1ES eller HA3.

Benyttede harmoniserte standarder, særlig:

se punkt 1

Benyttede nasjonale standarder, særlig:

se punkt 2

Declaramos pelo presente, que a máquina a seguir designada, na sua planificação e construção, assim como no modelo por nós comercializado, obedece às respectivas exigências fundamentais de segurança e de saúde.

A presente declaração perde a validade em caso de uso impróprio da máquina ou em caso de modificações na máquina, que não tenham sido acordadas antecipadamente conosco.

A declaração de conformidade é válida somente quando a máquina é accionada com o agregado hidráulico HA1ES ou HA3.

Normas harmonizadas aplicadas, especialmente:

vide parágrafo 1

Normas nacionais aplicadas, especialmente:

vide parágrafo 2

GENERAL SAFETY REGULATIONS


Read all safety regulations and instructions!

1. Keep the place of work clean.
Disorderly work-places and work-benches invite accidents.
Ensure that lighting is good.
2. Keep children away.
Do not allow unauthorised persons to touch the device or the cable.
Keep unauthorised persons away from your place of work.
3. Wear suitable working clothing.
Do not wear any wide clothes nor jewellery - they may get caught up in moving parts.
When working in the open it is recommended that you wear rubber gloves and non-slip footwear. Wear a hair- net if you have long hair.
4. Always be alert.
Only use a device after having been instructed in its operation.
Concentrate on your work. Proceed sensibly.
Do not use the device when you are distracted.
5. Do not lean too far forward. Avoid abnormal stance.
Make sure that you have a secure standing position, and maintain balance at all times.
6. Leave safety devices where they belong.
7. Hand tools may not be installed as fixtures.
8. Repair and maintenance.
Have repairs and maintenance work carried out in an authorised NOVOPRESS specialist workshop.
Only use original and identical NOVOPRESS spare parts.
We reject all responsibility and liability for work carried out by third- party personnel.

SAFETY INSTRUCTIONS FOR HYDRAULIC EQUIPMENT

1. Please read the operating instructions.
Acquaint yourself with the hydraulic equipment.
2. Provide the equipment with the necessary care.
Always keep the equipment in operational condition.
Cleanness is an essential requirement for good and safe working.
3. Switch off the electric power supply to the hydraulic equipment,
 - when the equipment is not in use
 - when maintenance work is to be carried out.
4. Avoid unintentional switching - on.
Keep hands and feet away from the switch when the equipment is not being used.
5. Do not use the equipment in a manner in contravention of the instructions.
Never carry the equipment by the pipe or pull on the pipe.
Protect the piping from heat, oil, sharp edges and high levels of weight strain.
6. Use only piping, fittings and accessories which have been designed for the operating pressure of the hydraulic unit.
BURSTING PRESSURE OR TEST PRESSURE IS NOT OPERATING PRESSURE!
Avoid squashing or bending of the piping.
Piping must not be painted over.
7. Replace the hydraulic piping
 - when cracks, squashed or bent points are to be seen
 - when blistering is established
 - when hydraulic fluid escapes
 - when pipe fittings are damaged
 - when discolouration is established on the outer layer, e.g. due to the influence of solvents.
8. The hydraulic fluid used in the system is kerosene-based.
This requires particular care and attention.
 - Avoid continuous contact with the skin
 - ensure that the hydraulic fluid does not get into the eyes or mouth.Hydraulic pipes have to be replaced after 5 years of usage, despite of the circumstance that no damages should be remarkable.
9. The equipment must not be operated, if it has leaks and there is a danger of hydraulic fluid coming into contact with persons, open fire, heating equipment, electric cabling, ground water, foods and other substances which are intended for human consumption.
10. Hydraulic units with petrol engines
 - must not be operated in closed rooms, due to the **DANGER OF INTOXICATION!**
 - do not pour in petrol while the motor is running or in the vicinity of open fire. **DANGER OF EXPLOSION!**

HSBL2 Hole punch 160 Digital, Order no.: 40280 and HSBL Hydraulic cylinder, Order no.: 2420



Range of application

The cylinder and hole punch are designed for a max. operating pressure of 150 bar.

The cylinder can be operated with the hydraulic units HA1 or HA3.

The following materials can be punched using the punching tool:

- Copper and aluminium rails up to a 160 x 13 mm and a maximum strength of 250 N/mm².
The maximum punch diameter is 18mm (21mm at 10mm rail thickness).
- Steel rails up to 160 x 6 mm and a maximum strength of 370 N/mm².
The largest hole diameter is 21 mm.

Any other or additional use is regarded as non-intended.


Novopress is not liable for any resulting consequences or damage. Neither is it liable for tools of other manufacturers nor for any damage caused by such.

Intended use also includes observance of the Operating Manual, adherence to the inspection and maintenance conditions as well as compliance with all the relevant safety regulations.


Technical data:

Height:	570	mm
Width	300	mm
Depth:	530	mm
Height inc. working cylinder:	990	mm
Total weight:	approx. 115	kg
Inner stand width:	450	mm
Punch stroke:	28	mm
Operating pressure:	Max. 150	bar
Force:	150	kN

Commissioning



1. Slide the hydraulic cylinder (1) with the cylinder tie bar (4) onto the punching assembly (10) and secure the holding pin.
2. Lift the tool guide (5) and slide until it hits the piston (6) of the cylinder and secure with both knurled screws.




3. The control lead (1) of the hydraulic unit must be connected to the code plug attached to the hydraulic hose. If necessary: connect control line to code plug.

Note!

The hydraulic unit can only be operated if the code plug is connected.

4. The cylinder is connected to the hydraulic unit with the snap coupling S.

Snap coupling



Coupling

Hold the coupling socket (KM) against the sliding sleeve (SH) and push onto the coupling plug (KS).


Uncoupling

Die Kupplungsmuffe (KM) an der Schiebehülse (SH) halten und vom Kupplungsstecker (KS) abziehen.



WARNING!

When assembling and disassembling the cylinder and during maintenance work, disconnected the hydraulic unit and the hydraulic unit power plug.

Tool installation





1. Insert the upper tool section (15) with the shaft in the mounting bore of the tool guide (5).. A bore in the tool shaft must be adjusted to the pin (16) of the tool locking device.




2. Slide the upper tool section up to the upper limit stop.
Note:
 Make sure that, after inserting the upper tool section, the pin is in its original position and not protruding. Non-observance results in damage to the tool.
3. **Note!**
The supporting surface for the lower tool section must be free from dirt, swarf etc.
 Insert the lower tool section (17) into the mounting bore of the punching assembly (10).

Note: When fitting profile tools, it is essential to ensure that the upper (15) and lower (17) tool sections are properly aligned.





4. In profile tools, the pin (20) of the lower tool section must lock into the corresponding bore (21) of the lower tool section carrier.




Note:

The lower tool section must be completely inserted into the lower tool section carrier. The lower tool section should not protrude from the lower tool section mounting.

5. Place the rail in the required punching position (see Page 10).

Punching

1. Operate the foot switch (F) (see Page 3). The rail is perforated.
2. Release the foot switch immediately after the punching procedure has ended. This avoids unnecessary heating of the oil.

Tool assembly**Upper tool section**

1. Pull out the pin (16) as far as possible and hold.
2. Remove the upper tool section (15).
3. Return the pin (16) to its original position.

Lower tool section

1. Press the lever (18) downwards
The lower tool section is raised from the mounting bore.
2. Remove the lower tool section (17).

Instructions for using the tools

- The hole diameter must not be smaller than the thickness of the material. Failure to observe this rule will result in damage to the tool.
- Enlarge holes using the **progressive die technique**:
The progressive die technique is only recommended for long-hole and profile tools. No clean progressive die stampings can be achieved using round tools.
Progressive die stampings are only permissible for tools with a minimum nominal dimension of 10mm.
In profile and long-hole tools, e.g. 16 x 10, progressive die stamping should only be executed on the long side, i.e. 16mm.
The overlapping of tools and materials should always be at least half the nominal tool dimension to ensure good punch quality.
Subsequent stampings should be a maximum of the "nominal tool dimension - 2mm" distance from the previous stampings to ensure that the whole material is punched out.
- **Change tools as soon as they become worn.**
Excess wear on a tool may cause the upper tool to become caught in the workpiece, and it may not be possible to wipe off the workpiece. The tool may be damaged when it is released.
- **Keep tools cleaned and oiled** when not in use. The tool life is increased by wetting it with a few drops of oil from time to time.
Storage of tools:
The upper tool must **not** be inserted into the lower tool, as this may damage the cutting edges.

Upper tool section

The upper tool section can repointed up to a minimum length of 38.0 mm.

Lower tool section

The lower tool section can repointed up to a minimum length of 19.0 mm.

Maintenance

WARNING! Before conducting any maintenance work, disconnect the hydraulic unit or disconnect the hydraulic unit from the mains.
- remove the tool to avoid injury.

Cylinder

Every week: - clean and oil the piston rod
 - clean and lubricate the holding pin

Every month: Inspect the cylinder for leakages and send off for repair if required.

Hole punch

Before each tool installation: Clean the mounting hole for the lower tool. The supporting surface must be free from swarf, dirt etc.

When dirty: - clean the rail-supporting surface

Every week: clean and oil the HSBL hole punch..

Every month: lubricate the hole punch using the lubricating nipple.

Tools

see Operating instructions

Guide system with roller conveyor and table

Range of application

The guide system, roller conveyor and table are used to position the rail.

Technical data

Guide system

Length:	2300	mm
Width	280	mm
Height:	60	mm
Stroke x-axis	2000	mm
Stroke y-axis	190	mm
Display accuracy	0,5	mm (standard 0.1mm possible)
Batteries	1,5	V Size C (Baby)

Roller conveyor


Length:	1950	mm
Roller width	400	mm
Frame width	450	mm
Height:	75	mm
Spacing of individual rollers	75	mm
Roller diameter	50	mm
Total weight:	approx. 15	kg

Table

Width	520	mm
Length:	520	mm
Height:	1400	mm
Total weight:	approx. 20	kg

Commissioning/Punching

1. Place the rail on the roller conveyor.



2. Place the rail at the limit stop (30).
3. Slide the press jaw (31) as shown onto the rail and fix with the clamping lever (32).

Information on operating the clamping lever

Lifting the handle releases the groove toothing and the clamping lever can be swivelled to the most favourable start position. When the lever is released the handle is automatically locked again.

It must be ensured that clamping levers are positioned so that, when the rail is moving, they do not collide with any other machine part.

4. Slide the limit stop (35) to the other end of the rail.
5. Slide the press jaw (36) onto the rail and fix with the clamping lever (37).
6. Fix the limit stop (35) with the clamping lever (38).
7. Slide the guide system by hand in the x-direction until the approximate required dimension appears on the digital display (45).
8. Set the required dimension in the x-direction using the control wheel (40).
9. Set the required dimension on the y-axis using the control wheel (41).
10. Operate the foot switch on the hydraulic unit (punching).
11. Release the foot switch immediately after the punching procedure has ended. This avoids unnecessary heating of the oil.

Operating the digital display of the measuring system




Battery charge level

- |||||▶ indicates the battery charge level.
the smaller the battery charge, the fewer lines are displayed.
This also indicates if the system is in display mode or parameter mode.
- |||||▶ on = display mode
- |||||▶ off = parameter mode

Setting the x-axis to zero


1. Slide the x-axis to the left up to the limit stop.



2. The edge (b) must correspond with the labelling on the lower tool section carrier.

Setting the y-axis to zero

1. Turn the y-axis as far as possible in direction of arrow.



2. The edge (b) of the limit stop must correspond with the labelling on the lower tool section carrier.

Resetting the digital display

1. Move the x or y limit stop to the corresponding zero setting.
2. Press the * key for approx. 3 secs.
"rEsEt" appears on the display:
3. Press the * key.
The previous set value appears flashing.
4. Press the * key.
The message "dOne" appears briefly followed by "0.0". The zero point for the corresponding limit is reset.


Note:

If the zero is cancelled, press the **P** key

Setting the incremental dimension

1. Move the rail to the position from which the incremental dimension begins.
2. Press the **P** and * keys simultaneously. The dimension "0.0" appears. This commences incremental dimension mode.
Note:
The decimal point flashes in incremental dimension mode
3. Move the rail to the required dimension.
4. Punch.
5. Press the * key for approx. 3 secs. The display is reset to zero.
6. Repeat points 3 to 5 as often as necessary.
7. To end incremental dimension mode, press the **P** and * keys. The absolute dimension is displayed
The decimal point stops flashing.

Example:



1. Set rail to dimension $x=20\text{mm}$ and $y=30\text{mm}$.
2. Adjust the x-display by pressing the **P** and * keys in incremental dimension mode. The following appears on the display: 0.0
3. Move the rail in the x-direction to the dimension 15mm.
4. Punch
5. Press the * key for 3 secs. 0.0 appears again on the display.
6. Move the rail in the x-direction to the dimension 40mm.
7. Punch.
8. Press the **P** and * keys. The dimension 75.0mm is indicated on the x-display.

Conversion of mm into inches and vice-versa

Press the **←** key for approx. 3 secs.

The set unit is indicated in the right-hand side of the display.

Setting of parameters

The digital display/measuring system provides the option for altering several parameters

The majority of these parameters are not required for punching and should not be altered.

The following table only shows the standard values for the parameters which should not be altered. The standard settings can be quickly checked and the factory settings reapplied with the aid of this table.

The parameters are displayed in a pre-established sequence. Pressing the P key switches the display to the next parameter and the value/setting associated therewith. The values/settings in the display flash.

The parameter name is always displayed first in the parameter menu, followed by the current value and current setting associated therewith.

To exit the parameter menu, press the **P** key for 3 secs.

To alter a parameter, select the parameter value, change the setting by pressing the **↑** key and then confirm the change with the * key. If the change is not confirmed with the * key, the original setting is maintained.

Changing a parameter

1. Select the parameter value.
2. Change the setting with the **↑** key.
3. Press the * key.
The setting has been changed.

Exiting the parameter menu

Press the **P** key for 3 secs.


Inputting a parameter:

1. Press the **P** key for approx. 3 secs. to change the parameter level.
"SEtUP" is shown on the display.
2. Press the **↑** key to access the menu.
3. The first parameter "Unit" is displayed.
4. Press the **P** key.
The first standard value "dEc" flashes on the display.
5. Press the **P** key
The second parameter "rES" appears on the display.
6. Press the **P** key until the entire menu has been run through, see also the following table.
7. The "rESET" parameter appears if the **P** key is pressed again.
8. Press the **P** key.
Firstly the message "no_rST" appears briefly.
Then "-----" appears
followed by the set value.
Display mode then reappears.


Parameter	Standard value	Other values	Comment
Unit	dEc		millimetres only
rES	0,5		Indicates the resolution with which the position display works 0.5 mm
		1	1 mm
		0,01	0.01 mm
		0,05	0.05 mm
		0,1	0.1 mm
dIc	uP		Count direction upwards (positive)
		dn	downwards (negative)
F_nnl	yES		Display mode can be changed from mm to inches using the ← key. active
F_rEL	yES		Release of incremental dimension function. active
		no	inactive
F_rSt	yES		These parameters are not required and should not be adjusted.
F_rEF	no		
F_oFS	no		

Adjusting the x-axis zero setting

1. Slide the x-axis to the left as far as possible.




2. The edge (b) of the limit stop must correspond with the height of labelling on the lower tool section carrier.
3. The edge (b) must correspond with the labelling on the lower tool section carrier. If this is not the case, reset the zero point as follows:




4. Loosen screw (20).
5. Set correct position.
6. Tighten the screw (20).
7. Press the * key for approx. 3 secs.
"rEsEt" appears on the display:
8. Press the * key.
The previous set value appears flashing.
9. Press the * key.
The message "dOne" appears briefly followed by "0,0". The zero point for the corresponding limit is reset.

Adjusting the y-axis zero setting

1. Turn the y-axis as far as possible in direction of arrow.
2. Slide the x-axis to the left as far as possible.



3. The edge (b) of the limit stop must correspond with the labelling on the lower tool section carrier.
4. If this is not the case, reset the zero point as follows:



5. Loosen nut (21).
6. Unscrew the grub screw slightly.
7. Adjust the y-axis with the dial so that the labelling on the lower tool section carrier corresponds with the limit stop.
8. Adjust the grub screw so that it comes into contact with the slide (W).
9. Fix the grub screw with the nut (21).
10. Press the * key for approx. 3 secs.
"rEsEt" appears on the display:
11. Press the * key.
The previous set value appears flashing.
12. Press the * key.
The message "dOne" appears briefly followed by "0,0". The zero point for the corresponding limit is reset.

Assembly

Required tools:


Open-jawed or ring spanner SW 13; SW 17

Hexagon socket screw key 5; 6


Spirit level

Folding rule


1. Place the hole punch on a table, workbench, etc.
2. Fasten the hole punch by means of the four holes in the feet.
3. Fasten the connector plates for the roller conveyors to the hole punch with 2 screws and 2 nuts.




4. Fasten 4 set screws (60) each with 2 nuts (61) to both plates.
5. Attach the roller conveyor supports to one end of the roller conveyor with 4 screws.
6. Set the dimension of the supports to approximately 990mm.
7. Attach a nut (62) to each set screw (60) so that the dimension 39mm is achieved.
8. Place the roller conveyor on these set screws.
9. Then align the roller conveyor so that a rail does not hit the green base of the hole punch but glide easily over it. Ensure that the roller conveyor in x and y-direction is aligned horizontally.
10. Secure the roller conveyor with a second nut.




11. Slide the hydraulic cylinder (1) with the cylinder tie bar (4) onto the punching assembly (10) and secure the holding pin.
12. Lift the tool guide (5) and slide until it hits the piston (6) of the cylinder and secure with both knurled screws.



13. Remove 2 screws (50) from the sensor fastening plate (51).
14. Remove the sensor fastening plate (51) and place behind the digital display.
15. Undo 12 screws (52).



16. Slide the x-axis with the fastening plate (57) into the hole punch frame so that the preassembled limit stop is to the right of the hole punch frame.
17. Place the fastening plate (57) on the four screws (53).
18. Secure the fastening plate (57) with 12 screws (52).
19. Place the plate (51) with the sensor on the fastening element and slide into the groove of the guide rail.
20. Attach the plate (51) with 2 screws (50).




21. The guide rail contains a sliding block (56) for attaching the second limit stop. The sliding block must be positioned to the left of the hole punch. Slide the sliding block to the left-hand side if necessary.
22. Attach the second limit stop to the guide rail with the aid of the clamping lever and the sliding block.

Information on operating the clamping lever

Lifting the handle releases the groove toothing and the clamping lever can be swivelled to the most favourable start position. When the lever is released the handle is automatically locked again.

It must be ensured that clamping levers are positioned so that, when the rail is moving, they do not collide with any other machine part.

23. Screw the clamping lever of the second limit stop into the sliding block.



24. Place the control wheel (40) on the guide rail.
Ensure that the pinion engages the tothing of the guide rail.
25. Secure both screws (43).
26. Slide the x-axis manually to the left.
27. Check the zero setting of the x and y-axes (see Pages 11 and 12).

Repairs / Service

novopress

Scharnhorststrasse 1
D-41460 Neuss

PO Box 101163
D-41411 Neuss
Tel. 02131 / 2880
Fax 02131 / 28855